

Collar Modification Kit

For Attachment of JRB Down Hood

1. Enclosed is a 24 inch piece of omni tape. You will need 20-22 inches of it to modify any standard stand up collar found on quarter, half, and full zip outdoor jackets or tops.
2. You will need some 100 percent polyester or nylon thread. Do not use any cotton core poly thread as it will not hold up in the outdoor environment.
3. First, cut a 1 inch piece of the omni tape. Center it on the back of the collar at a point $\frac{1}{4}$ inch above the bottom of the collar or neck line at the shoulder center. Be sure to sew the sewing tracks top and bottom and endeavor to stay in the tracks. Whenever you sew across the end of omni tape it is important to make three passes, as all Velcro products have a way of coming loose if not adequately sewn.
4. Next, position a piece of omni tape to one side of the now attached center piece. Align the omni tape to end at the zipper seam $\frac{1}{4}$ inch from the top. Cut the ends parallel with the center piece and the zipper seam. Sew the now formed parallelogram in place.
5. Repeat step 4 on the opposite side.
6. Your jacket modification is complete.
7. To attach the JRB hood, fold it in half to find the center and then attach the hood beginning at the center and proceeding to each end. Press the omni tape firmly together. You will note that the hood omni tape is approximately 1-2 inches longer (depending on the jacket size) than the collar on each end. This enables you to leave the hood somewhat open at the bottom for some neck ventilation or attach the two protruding section of omni tape for a good neck seal when needed.

